



D-link PowerLine Hard Rest

Hard reset, for times when the blue light flases and the hard reset fails.

Written By: alan



INTRODUCTION

I phoned D-Link tech support several times, and they eventually concluded my device was broken, but I got it fixed.

My D-Link dhp w306av would do nothing but blink it's blue (WPS/ENY) LED. None of the support people could fix it with any kind of reset. This is what I managed to do.

Step 1 — D-link PowerLine Hard Rest



- ❗ (With router unplugged, and no ethernet cable attached) Turn the router on (push in the power button on the side) remember it's not plugged into the wall yet.

Step 2



- Take a pin or micro screwdriver and push in and hold the reset button.
- Still holding the reset button plug the router into a power outlet.
- Keep holding down the reset button for at least 15 seconds.
- ❗ If you have the same luck I did your green lights on the side will start to cycle and light up.
- Now you can go back to your quick install guide that came with the router and set it up again.

hope it works for you

